## City of San Angelo 72W College Ave 2nd Floor San Angelo TX 76902

## TAILGATE/TOOLBOX SAFETY TRAINING

Safety Services Company-Safety Meeting Division, PO Box 6408 Yuma, AZ 85366-6408 Toll Free (866) 204-4786

#187108
SAFETY
SERVICES
COMPANY

Job Name:	Job Site Location:	1
	Finish Time: Foreman/Supervisor:	
Introduction: Following is an inspection check Pre-trip inspection for tractor/trailers: Have  When approaching the semi, look for leak Check under the hood for water and crank Check the fan and compressor belts for cr Start engine and set at fast idle for warm-to check gauges for normal readings (pilot I Anti-lock warning light should light brieff Check emergency equipment, horn(s), and Turn on all lights including 4-way flasher Switch headlights on and check both beam Check front clearance and identification lights.  Check right side of cab, door, mirrors, etc. Check right rear tractor tires, wheels, lugs. Check trailer light and brake lines for sect open. Be sure lines are properly secured to Check hook-up, fifth-wheel, jaws, and rel. Check pintle hook, tow bar, safety chains, Check rear of body, mud flaps, rear lights.	Finish Time: Foreman/Supervisor:	60 pounds.  only. Leave all other lights on. for leaks around hubs.
<ul> <li>□ Check left rear tractor tires, wheels, lugs,</li> <li>□ Re-enter cab. Re-check all gauges. Air production</li> <li>□ Check parking brake.</li> <li>Older tractors (pre-121 brakes): With fully of the production</li> <li>□ Put trailer air supply valve in normal. Use</li> <li>□ Release treadle valve and put trailer air supply valve to normal at 60 PSI. Between 45 and 20 PSI, the trailer</li> <li>New tractors (equipped with 121 brakes): We driver must remain in vehicle ready to reapply</li> <li>□ Release all parking brakes.</li> <li>□ Push trailer air supply valve to supply. Use</li> <li>□ Release treadle valve. Place tractor park verification</li> <li>□ Apply tractor-trailer park valve. Trailer be primary reservoir, low air warning should</li> <li>All tractors: Recharge system to check for least paper of the primary in the primary reservoir in</li></ul>	or studs. Check for thrown lubrication.  cessure should be at maximum.  Check brakes and stoplights.  Charged system, check air brakes as follows:  treadle valve to apply and release.  pply valve in Emergency. Trailer brakes should come on and stay on.  Ind fan down brakes. Recheck for activation of low air warning at release should come on.  ARNING: Because many of the following checks must be performed with parking brakes if necessary.  The treadle valve to apply and release brakes.  The treadle valve t	should not exceed 4 PSI.
☐ Make a test stop before leaving the yard. I	d right turn signals. Proper operation of turn signals can be ascertained by c Drain air tanks daily. Check tires twice daily or every 100 miles. his inspection checklist before heading off down the road.	hecking front ones.
Work Site Review		
	S:	
Employee Signatures:	(My signature attests and verifies my understanding of and agreement to comply and regulations, and that I have not suffered, experienced, or sustained any re	